



time to relax

TWIST²GO





< timetorelax

For over 25 years, CASADA Deutschland GmbH has been firmly established in the wellness and fitness market. Our products are available worldwide in numerous countries and stand for functionality, modern design, and reliable quality.

At CASADA, you and your well-being are our top priority. We place special emphasis on user-friendliness, safety, and durability, so that you can integrate our products comfortably and reliably into your daily life.

High quality standards as well as the continuous development of our product range form the basis for the trust of our customers around the world.

Congratulations!

By purchasing this massage device, you have chosen a high-quality product from CASADA. To ensure long-term and safe use of your device, please read and observe this user manual carefully, especially the safety instructions.

We wish you much enjoyment and many relaxing moments with your personal Twist2Go.

Table of contents

Safety instructions	10
Inside the package	10
Start up	10
Technical data	11
Specials	11
Optional Accessories	12
Control panel	12
Troubleshooting	12
Storage / care	12
Conformity declaration	13
Warranty conditions	13

Important Safety Instructions



Please read the following instructions carefully before using the device for the first time to ensure safe operation and proper functionality. Keep this user manual for future reference.

- This massage device complies with the recognized rules of technology and the applicable European safety regulations.
- The device is maintenance-free. Repairs may only be carried out by authorized specialist personnel. Improper use or unauthorized repairs will void the warranty.
- Never touch the power plug with wet hands
- Do not expose the device to moisture, extreme temperatures, or direct sunlight.
- Disconnect the device from the power supply if it will not be used for an extended period of time.
- Do not use the device if the power plug, cable, or housing is damaged. Damaged components must be replaced by the manufacturer, an authorized service partner, or qualified specialist personnel.
- In the event of malfunctions, disconnect the device from the power supply immediately.
- Do not exceed the recommended usage time of 30 minutes.
- Do not use sharp or pointed objects on the device.
- Do not use the device if you are pregnant or if you have complaints in the massage area such as recent injuries, inflammations, swelling, thrombotic conditions, or tumors. If in doubt, consult a physician before use.
- Do not use the device while driving.
- Persons with medical implants (e.g. pacemakers) must consult a physician before using the device.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the safe use of the appliance.
- Children should be supervised to ensure that they do not play with the appliance.

Inside the package

- Twist2Go
- Adapter
- Car adapter

Start up

Before initial operation, check whether the voltage indicated on the power plug matches your local mains voltage.

Then connect the power cable to the massage device and plug the power plug into a suitable socket.

With the supplied car adapter, the Twist2Go can also be used on the go.

Use during driving is not permitted.

Insert the car adapter into the vehicle's cigarette lighter.

Technical data

Measurements:	35 x 23 x 15 cm
Weight:	1,8 kg
Voltage adapter: input: output:	100-240 V ~ 50/60 Hz, 0.8 A 14 V $\approx$ 1.7 A
Voltage device:	Lithium battery 11.1V/2200 mAh
Rated power:	24 watt
Runtime:	1 – 1,5 hours
Charging time:	3,5 hours
Certificates:	       

Special Features / Functions



KNEADING MASSAGE

A proven massage technique in which the skin and muscles are gently grasped and kneaded. It is often used to relieve tense muscle areas.



HEAT FUNCTION

The integrated heat function provides pleasant deep warmth and supports a relaxing massage experience.



WIRELESS

The Twist2Go allows cordless use for maximum flexibility.



THUMB PRESSURE TECHNIQUE

Ergonomically shaped massage heads modeled after human thumbs provide a particularly authentic massage sensation.

Optional Accessories

Straps: The separately available straps allow precise positioning of the Twist2Go on exactly the area of your body you wish to treat. They can be easily attached to and removed from the device. This allows you to individually control intensity and pressure – for maximum flexibility even without a support surface.

Cover: A soft cover is available for an especially gentle and pleasant massage experience. It provides additional comfort and allows the device to glide more smoothly over your skin. Further information and possible accessories can be found at casada.de.



Control Panel

- [1] On / Off
Press this button for approx. 3 seconds to switch on the device. The kneading/Shiatsu function starts and the heat function is activated. To switch off, press and hold the button again for 3 seconds.
- [2] Heating
Activates or deactivates the heat function.
- [3] Geschwindigkeit
Switches between two speed levels.



Troubleshooting

Error	Adjustment
The massage device cannot operate even though it has been connected to the power supply.	• Check the connection of the adapter. • The device could be overheated after prolonged use. It will automatically cool down to resume its normal condition. Please turn off the power and allow the device to cool off for 30 to 50 minutes.

Storage & Care

Regular care will extend the life of your Twist2Go whilst also ensuring safe operation at all times.

1. Recommended storage: dry, free of dust.
2. Keep liquids and open fire away from the Twist2Go.
3. Clean the equipment using a dry, soft cloth.
4. Always unplug the Twist2Go when not in use.

Conformity declaration

Corresponds to the European guidelines EMC 2014/30/EU, LVD 2014/35/EU.

Warranty conditions

The retailer grants the statutory warranty period for this product from the date of purchase. Please keep your proof of purchase carefully as evidence.

In the event of justified defects, the retailer shall bear the costs for repair or replacement of the device, including necessary shipping costs, insofar as this is provided for under applicable legal provisions. Excluded from this are wear parts, such as fabric covers, as well as damage caused by improper use or external influences.

The warranty applies only when the device is used as intended in accordance with this user manual.

Repairs or modifications carried out by unauthorized persons will void the warranty.

Please report any obvious defects to the retailer immediately after receiving the device. Further liability claims, in particular for consequential or indirect damages, are excluded. Damage resulting from failure to observe this user manual or from misuse is also not covered by the warranty.

Statutory warranty rights against the retailer remain unaffected and may vary depending on the country.

Casada Deutschland GmbH
Obermeiers Feld 3
33104 Paderborn, Germany
info@casada.de
www.casada.de

Copyright Images and texts are subject to the copyright of Casada Deutschland GmbH and may not be used for other purposes without express confirmation.
Copyright © 2026 Casada Deutschland GmbH. All rights reserved.



This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

